





IMPORTANT! Please read these instructions **prior** to installation

Distributed by:



Exceptional Bathrooms. Exceptional Choice. T 04 568 9898 E sales@plumbline.co.nz www.plumbline.co.nz

Pucci Single Flush Panel





1. Take off the face plate



3. Unclip the rod from the entry cover



5. Screw on the new entry cover



7. Bring blue clips to 16 mm



2. Unscrew and remove the support frame



4. Clip the rod onto the new slim entry cover



6. Screw the slim frame + the spacers onto the entry cover



8. Engage the face plate from bottom to top