
INSTALLATION INSTRUCTIONS







IMPORTANT!

Please read these instructions prior to installation

Distributed by:




RECOMMENDATIONS FOR INSTALLATION



ATTENTION: Failure to follow these recommendations may void the warranty. It is recommended that a qualified, licensed tradesperson install this product.





Water Pressure: 3 bar

Product performance cannot be guaranteed if pressure is less than 1 bar. Above 5 bar a pressure regulator must be installed. Failure to do so voids the product warranty. Water Temperature: 45°-65°C



Pre-Flush

Always flush out the pipework before connecting any tapware. Failure to do so voids the product warranty.


INSTALLATION INSTRUCTIONS

V 20 03 2023


BEFORE WALL LINING


- 1 Men preparing the wall for pipework and suitable fixing points for the mixer body, ensure that the finished wall surface is within the minimum/ maximum parameters shown on the protective box.
- 2 Connect the hot & cold water inlet pipes and the outlet pipe.
- **3** Fasten the mixer body to sufficient framing, ensuring that it is level.

A Pressure test the unit before wall lining.




Min






AFTER WALL LINING


- 4 Cut the protective box back to the finished wall surface.
- 5 Install the flange & handle. It is recommended to apply a small bead of silicone behind the faceplate to prevent water entering the wall cavity.
- 6 Test for perfomance








CLEANING & MAINTENANCE




Cleaning

Clean with warm soapy water and a smooth cloth. Avoid abrasive sponges or detergents as these will damage the finish.

To preserve the finish it is recommend to apply a stainless steel oil/mineral oil on a monthly basis.





Cartridge Replacement

Before you start, turn off the water supply to the mixer.

- 1. Remove the handle
- 2. Unscrew the dome (hand tightened)
- 3. Unscrew the locking nut
- 4. Remove the cartridge

Re-assemble in reverse order

Max tightening torque on locking nut: 10-12 Nm

Warranty Information

For full details about our warranty visit plumbline.co.nz/warranty-information