


# INSTALLATION INSTRUCTIONS

## SPIO INSET BATHS

progetto  
DESIGN COLLECTION



### IMPORTANT!

Please read these instructions **prior** to installation

Distributed by:

**Plumblīne**

T 04 568 9898 E [sales@plumblīne.co.nz](mailto:sales@plumblīne.co.nz)  
[www.plumblīne.co.nz](http://www.plumblīne.co.nz)


## Cleaning Guide

Matt Solid surface products require minimal maintenance. For every day cleaning after each use, simply wipe with a soft wet cloth to remove any surface dirt.

For tougher marks we recommend using widely available cleaning products such as liquid jiff. Occasionally you may require a mildly abrasive product to erase scratches like P800 grit sandpaper.

**Never use petroleum-based products when cleaning, i.e. paint thinner or other solvents, as they may damage the solid surface.**

Personal hygiene products and cosmetics will NOT damage the surface.



Wipe surface with a soft cloth after each use. Use a mild cleaning product. For more difficult stains, use a mildly abrasive cream cleanser.

---

## General Installation Instructions

### IMPORTANT



Please unwrap the bath and check it carefully to ensure it has not been damaged during handling or transport, and check that all parts have been supplied.

It is recommended that the bath is assembled (if required) on a mat to protect against damage to the bath surface.

Store the bath in a safe place until you begin installation.

Installation should be carried out by a qualified, licensed tradesperson.

1. Install waste pipe in accordance with the set out. Check the waste pipe aligns accurately with bath waste. This bath must be installed with a top fix waste (Reccomended waste - code: 900075).
2. Create a frame for the bath to sit inside, constructed from wood, masonry or steel. This bath is not self supporting and requires a bed of sand/ cement slurry to support the base of the bath.
3. Once the wall has been lined, place the bath in position and connect the top fix waste.
4. Fill the bath and then release, checking seals for leaks and that the bath drains successfully.
5. Apply flexible sealant to the exposed edges.



**IMPORTANT:** Avoid tiling over the bath or tiling it in as this will void the warranty.



**IMPORTANT!**

This bath is not self supporting and does require a bed of sand/cement slurry.

## Warranty Information

- Solid Surface Baths: Ten (10) Year warranty from date of purchase.

Plumblin will undertake to replace free of charge any faulty product due to defects in materials or manufacturer workmanship within the warranty period (Proof of purchase must be retained). Plumblin will also cover labour costs within 2 years from purchase for the replacement or repair of any Plumblin supplied product that is deemed by Plumblin technicians to be faulty or defective.

Plumblin (or their approved retailer) reserve the right to assess, repair, replace or service any warranty claims as they see fit.

The above warranties are upheld providing the products have been used for normal domestic only and exclude any defect or injury caused by or resulting from misuse, abuse or neglect, accidental damage, improper installation or other alterations or modifications which affect the reliability or performance of the item not attributed to faulty manufacture. The above warranties do not apply to the replacement of products where damage is caused by normal wear and tear, where the hot water temperature exceeds 55°C or where the warranty claim has not been notified to Plumblin (or their approved retailer) within ninety (90) days of the problem first appearing.

Where a claim is for a 'visible fault' on a product after it has been installed and it is established that the fault is visible and should have been detected before installation, only the product will be replaced. Removal and re-installation costs are the responsibility of the installer/customer.

The above warranties do not include consequential loss or damage due to the product.

**IMPORTANT NOTE: This warranty does not cover the removal/replacement of tiles/wall liners where the bath has been tiled or fitted 'into' the wall.**